

## Frame robustness test equipment

### **Description:**

The test equipment comprises two major assemblies:

A adjustable supporting fixture for the test specimen ;

A test mass which applies the specified force through a dial test indicator, and a second DTI which measures the deflection of the specimen frame.

These are mounted on a substantial base plate.

### **Services required:**

Bench mounted

### **Approximate packed size & weight:**

30 x 20 x 20 cm : 10 kg

### **Relevant standards:**

EN 1836:2005, clause 6.10.1 and figure 4  
ISO 12870, clause 8.4.1 and figure 3

