

European polyurethane headforms (medium and small)

Description:

These headforms are manufactured with a rigid cast aluminium core, covered with polyurethane to simulate flesh/skin.

Each headform is provided with two removable 'ear pins' to support spectacle side arms.

These headforms are used for impact tests on protective eyewear, including ballistics tests and drop ball tests.

Services required:

None

Approximate packed size & weight:

40 x 35 x 25 cm : 7 kg

Relevant standards:

EN 168:2001, clause 17 and figure 11
AS/NZS 1337-1:2010, clause 1.4.6 and figure 1

Medium headform



Small headform

