

## ANSI Lanyard abrasion test equipment

### **Description:**

This equipment allows the specimen lanyard to be abraded over the specified, hardened, hexagonal steel bar at the rate, and for the number of cycles, given in the standard.

A user adjustable counter allows the number of cycles to be altered.

### **Services required:**

Floor mounted  
110/230 Volts AC, 50/60Hz, mains electricity

### **Optional items:**

Supplies of hardened, hexagon steel bars

### **Approximate packed size & weight:**

130 x 80 x 55 cm : 80 kg

### **Relevant standard:**

ANSI Z359.13:2013, clause 4.1.9 and figure 7

