

## CSA Connector abrasion test equipment

### **Description:**

The specified, hardened, hexagonal steel bar is rotated at the required speed by an electric motor for a predetermined number of revolutions.

Adjustable stops are fitted to the hexagon bar to allow different portions of it to be used for successive tests.

Four weights are provided, so that up to four connectors can be tested simultaneously.

A user adjustable counter allows the number of revolutions to be altered.

### **Services required:**

Floor mounted  
110/230 Volts AC, 50/60Hz, mains electricity

### **Optional items:**

Supplies of hardened, hexagon steel bars

### **Approximate packed size & weight:**

160 x 75 x 70 cm : 70 kg

### **Relevant standard:**

CSA Z259.12:2011, clause 6.4.1.1 and figure 20

