

Flammability test equipment

Description:

The equipment comprises a propane gas burner of 10mm diameter bore, U-tube manometer and connecting tubing.

A retort stand clamping arrangement to secure the helmet during the test is also provided.

Optional item:

Digital thermometer (hand -held and battery powered) and thermocouple probe for ANSI Z89.1



Services required:

Bench mounted (fume cupboard)
A supply of compressed propane gas which should be sourced locally

Approximate packed size & weight:

80 x 20 x 20 cm : 4 kg

Relevant standards:

EN 397:2012, clause 6.8.2
EN 812:2012, clause 6.8.2
EN 13087-7:2000, clause 5.3
AS/NZS 1801:1999, appendix E4
ANSI Z89.1:2014, clause 10.1 and figure 12