

## European polyurethane headforms (medium and small)

### Description:

These headforms are manufactured with a rigid cast aluminium core, covered with polyurethane to simulate flesh/skin.

Each headform is provided with two removable 'ear pins' to support spectacle side arms.

These headforms are used for impact tests on protective eyewear, including ballistics tests and drop ball tests.

### Services required:

None

### Approximate size & weight:

40 x 35 x 25 cm : 7 kg

### Relevant standards:

ANSI ISEA Z87.1:2012 Annex B  
EN 168:2001, clause 17 and figure 11  
AS/NZS 1337-1:2010, clause 1.4.6 and figure 1  
ISO 12311:2013  
ISO 12312-1:2013, Part 1

Medium headform



Small headform

