

## EN 12277 Test dummy

### Description

The torso is made using a hard epoxy resin with steel studding and eyebolts according to the dimensions specified in EN 12277:2015 figure 4. It is intended for testing harness types A, C and D as specified in clauses 5.2.3, 5.2.5, 5.2.6 of EN 12277:2015.

The test dummy for testing Type B harnesses is also available from INSPEC.



### Services required

Tensile test equipment capable of applying 15kN.

### Approximate size & weight

800 x 500 x 250 mm : 32 kg

### Relevant standard

EN 12277:2015, clauses 5.2.3, 5.2.5, 5.2.6 and figure 4